



Agenda

Fundamentals



- 10 Basic Concepts
- So you have a Blank Piece of Paper...
- Elements, Dimensions and Real Speed
- Summary and Questions



Fundamentals

avoiding the stuff that can mess up a perfectly good course

- Make a scale map
 - Show "known places"
 - Benefits of a scale map
- Then place start and finish lines
- Timing and scoring location
- Consider placement of the course workers
 - Safe workstation positioning
 - Ensure they can See all of the pylons within their responsibility
 - Keep pylons close enough so they can be placed without start delay or a red flag
- Check out the conditions of the surface
- Allow for multiple cars (site and timing software allowing)
 - Can two cars (or more) safely be on course at once?
 - Do adjacent section conflicts prevent full use of the time available?
- Follow the "10 Basic Concepts"



Fundamentals

How to Keep Your Peers from Killing You...

Do Notice

Do Not get them lost or make them hit cones!

Do Not include too many pylons creating a "Sea of Pylons"

Do Not space pylons the same or similar distance as the gate width

Do Not place the next gate out of their line of sight

Do Not fail to line the course (when possible)

Do Not place a cone(s) thinking "boy, will THAT one get creamed!"



Fundamentals





- So you have a Blank Piece of Paper...
- Elements, Dimensions and Real Speed
- Summary and Questions



10 Basic Concepts

- 1.) Be a Commercial Artist
- 2.) Use Creativity
- 3.) No Hidden Agendas
- 4.) Be Familiar with the Autocross Course Design Rules
- 5.) Make the Course Flow
- 6.) Use Elements that Favor Horsepower and Elements that Favor Handling
- 7.) Use Pointers and Directionals Correctly and Sparingly
- 8.) Line the Course, when possible
- 9.) Place Gates to Avoid Visual Confusion
- 10.) Walk/Drive Your Course with the Intent of Improvement





1.) Be a Commercial Artist

- As a course designer, you will become an artist; according to Webster, an artist is "one who professes and practices an imaginative art"
 - Believe me, imagination is required to create a course that is interesting and fun to drive - and when the course design is completed, you will feel like you have created a piece of art!
 - A Fine Artist is:
 - An artist whose main goal is to please themselves, and then everyone else can like it or 'stuff it'
 - A Commercial Artist is:

 An artist whose main goal is to please the customer, while pleasing themselves as well


Be a Commercial Artist not a Fine Artist





Set yourself Up for Success

- The main goal of course design is to provide the competitors with Fair, Fun and Safe Competition
- After creating a course design, take copies of it to be reviewed and critiqued by your peers (never destroy the original)
 - Listen and hear to what they have to say
 - Ask them to explain the 'hows and whys' of their suggestion
 - Mark your map up with their suggestions and comments





Set yourself Up for Success

- After the peer review
 - look over and analyze their comments and implement any that improve the design
 - Address all safety related comments
 - Be true to your basic concept
 - Put your own style into their suggestion; that is why you got the 'hows and whys'
- The great thing about "advice" is:
 - You don't have to take their advice, and you might learn or see something you had not thought about





10 Basic Concepts - Be a Commercial Artist

Judging your Success

Since you're yelling at me, should I assume you didn't like it?

- At the event, ask the competitors about your course directly and listen to what they have to say
 - · What did they like/dislike and why?
 - If your favorite element is criticized every time that you use it;
 re-think it don't force your fellow competitors to accept it
 - Try to 'eaves drop' for comments about the course
 - Don't get discouraged if some people do not like the course
 - Remember: those who have won will love it; those who have lost tend not to...
- Did you receive unsolicited praise or complaints?
- Watch for number and frequency of cones hit
 - If almost every car is hitting "that cone", the course will likely not be well received
- Note the number of delays and track the number of DNFs


Provide Autocross competitors with Fair, Fun and Safe Competition





2.) Use Creativity

- Creativity is what makes a course interesting to drive
- What is creativity in course design?
 - Rewarding those who find the right amount of skill, aggression, and discipline
 - Placing challenge in the design without making it "painful"
 - Setting up an often used maneuver in a different manner
 - Including a variety of different turn-types and transients
- Be creative and innovative
 - When you come up with a new concept that you believe to be new and creative, take a moment to analyze it
 - Is it so creative that it has become **BIZARRE**?
 - If so, modify the idea or forget it, because it will not be well received by most drivers









Application of Creativity

Include turns of varying radii and speed


- Sweepers should come in various sizes, possibly even with changing radii
- Don't design a course consisting primarily of 180° turns
 - use 90°, 180°, 60°, fast 45° turns, etc.

Provide a variety of car path directions

 Use the various turns to send the car in directions not always perpendicular or parallel to the site outside perimeter or the site markings on the surface such as paint stripes or concrete squares

Provide a variety of transients


- Straight slaloms / offset slaloms
- Sequences of offset gates
- Lane changes
- Combinations of the above
 - Challenging courses include combinations of transients that require a
 precise entry into the first part of the combination in order to drive through the
 entire combination quickly





10 Basic Concepts - Use Creativity


5 Cone Slalom






10 Basic Concepts - Use Creativity


5 Cone Slalom (continued)



Version B; Change for interest



Note: Version A & B are both 240' long. Version B offsets one cone width for each gain of 10' in slalom length, resulting in a more interesting maneuver of the same nature. The increase in distance prevents the maneuver from becoming painful




Note: Cones 1 & 2 are offset 3' the hard way with cone 3 offset 1.5' the easy way. This opens up a "Lotus freeway" through the last 3 cones of the slalom. To make the punishment bearable, be sure to allow adequate set up area prior to the punishment, otherwise the punishment becomes painful




10 Basic Concepts - Use Creativity

The "Before and Afters"

Placement of the gate "before and after" the start and finish of a slalom is critical as to the amount of turns that the slalom actually becomes









example 3

10 Basic Concepts - Use Creativity

Which is easiest to See?





You must also consider if the inclusion of your "creative" cone placement has reduced clarity of the course significantly

The surrounding cones from the following maneuvers may impact the clarity

For instance, if you have several walls of cones following this slalom, example 1 would be most appropriate; and if not, examples 2 or 3 might be more appropriate



The Brainer


The intent of a "brainer" is to allow a fast line through, but give it the visual effect of a slow maneuver. This will then give the competitor a reward, or a "doggy bone" for figuring it out.




The wall at the 180° will tend to make an unwary competitor square the corner out. The driver who looks carefully will round the corner out and use the lack of wall to their advantage



Competitors that don't "read" the course tend to drive cone to cone. The indicated cone will tend to pull in a driver who has not thought this one out. The fast line is to stay wide to make a sweeping turn.



note lack of wall here





3.) No Hidden Agendas

 You should not accept a course design job for any reason other than a desire to design a course

- If you are not really interested in the design of it, you will not create a good course
 - If you have gotten the responsibility 'by default', (i.e. event chairman) get someone who is truly interested in designing a course instead
- Avoid designing the course on the premise of favoring your car
 - Example; Corvette versus Miata
 - Corvette: 1000' straight, 180° turn, and a 1000' straight
 - Miata: offset slaloms connected with 30' radius offset gates





With a hidden agenda the result is a course that only a few people enjoy - or perhaps even a course that **NO ONE** will enjoy!





4.) Be Familiar with the Autocross Course Design Rules

Basic Concept 4.) refers to the rules found in Section 2.0 of your Autocross rule book

- By knowing the rules in Section 2.0, you will be able to create an Autocross course design that is acceptable to your peers as well as the Autocross Safety Stewards
- The following are diagrams taken from some of the 2022 rules
 - ALL of the rules, of course, are important and should be known/understood - these are just the rules that I perceive to have the most impact on your design decisions



SCCA® National Solo® Rules

2022 EDITION

Sports Car Club of America® Solo® Department 6620 SE Dwight St. Topeka, KS 66619

> (800) 770-2055 (785) 232-7228 Fax

www.scca.com








2.0 Diagrams

2.2.C The course boundary shall not normally pass closer than 25 feet from solid objects
 2.2.D karts... upright solid objects (e.g., light poles, fence posts, etc) on the site within 50 ft. of the actual course. This does not include curbs

The "better" example shown here is considered minimum. Greater distances from Stationary objects is always better







2.0 Diagrams (continued)

2.2.M Participants and non-participants must be kept at a safe distance... ...minimum viewing distances may not be less than **75' from the course edge in unprotected areas** (areas without adequate barrier protection such as concrete or tire walls)...

The preferred example shown here is considered minimum. Greater distances from Spectator Areas are always better. Fast course sections should never aim directly at spectator areas without very large runoff distances





Area





Area

2.0 Diagrams (continued)

2.2.E Special caution should be applied where negative-cambered turns are used.

Note:









2.0 Diagrams (continued)

2.2.F A long straight (over 150') should not terminate in an extremely sharp turn...








2.0 Diagrams (continued)


2.2.H Cars on course simultaneously shall not run in close proximity to each other

"Close Proximity"... The definition of this is ultimately up to the **Safety Steward**, but if you consider rule 2.2.L, the absolute minimum would be **75'**. Obviously, the more drastic the maneuver, the more space that should be allotted. The whole idea of this rule is to keep 2 competitors from colliding in the event of one (or both) of them losing control or getting lost on course.


Unacceptable



Acceptable



Better Yet





5.) Make the Course Flow


"There's no such thing as a car that can turn on a dime..." K.C. Babb

- It's not necessary to get into third gear in order to have a fun course
 - The level of "fun" will more likely be determined by the flow of the course instead of the highest attained speed
 - If you feel like you've gone fast without violating the speed paradigms, then your design is a success
- So, then what is the "Flow of the Course"?
 - The flow refers to the way adjacent sections of a course connect to each other



10 Basic Concepts - Make the Course Flow


"Flow Like a River"





Non-Flowing Maneuvers to Avoid


- There are also a few "No Fun Maneuvers" (NFMs) that should be avoided if possible
 - Any maneuver that requires a 1st gear down shift
 - 360 degree pivot turns or also known as a spin cone
 - Narrow, walled in sharp turns
 - Gates or Slaloms with severe offsets and short spacing (45' spacing; 10' offset)
 - Two 90 degree walled in turns (shaped like a "Z")
 just before the finish lights, which is O.K. for a start –
 but no way to finish!
 - Hitting the brakes hard just before the lights








Locating Key Cones





Gate Width versus Speed





Advantages of wider gates

- Choosing the superior line requires more skill and experience
- Allows for mistakes/sloppiness with no pylon penalties
- Easier on course workers and timing & scoring



Remove a Slalom Cone






• By **removing** only **one cone** in this 300 foot slalom, you are able to open up the slalom to a more reasonable spacing of 54 feet. This is not a "wide open" slalom and definitely flows better than the example on top. You can also make the slalom a **gradually increasing** allowing the more astute course walkers the chance to pick up on a feature that not everyone will realize





Lock to Lock Turns

No lock to lock turns








Lock to Lock Turns (continued)


painful

Generally, avoid 180° turns. If required by lot shape, don't make lock to lock steering inputs just before entering the 180



better

- Open up the entering maneuvers
- Allow plenty of setup area to enter/exit a 180° turn









Avoid "Painful" Walled in Turns

Painful




Better

solutions keeping the same flavor as the original




1 flowing turn...







Line of Sight and Gate Positioning


Bad




Better













6.) Use Elements that Favor HP and Elements that Favor Handling

- Use both types of elements to create an "equalizer" course
 - This would be one where a 2022 Camaro SS 1LE would have no advantage over a 2008 Mercedes C300, which in 2022 are both in FStreet
 - By doing so, you will have a much greater chance of pleasing the majority of the drivers in attendance
- First decide what favors horsepower and what favors handling
 - Then evenly apply those kinds of maneuvers in your design
 - In a over simplified explanation:

horsepower

straights (duh...)
long spaced slaloms and large radius sweeping turns
sharp turns (90 degree or more)
maneuvers connected with straights
open maneuvers

etc.

handling

short to medium spaced slaloms small radius sweeping turns chicane/lane changes successive maneuvers tight maneuvers

etc.


- A straight is any area where full acceleration can be utilized, and is not just the classic definition of the shortest distance between two points
 - A slalom spaced greater than 100' can be considered a straight



10 Basic Concepts - Horsepower and Handling

Utilize "the Gap" to Help Control Speed

Use either easy or difficult maneuvers to speed up or slow down a course without disrupting the flow



As was mentioned earlier, it is very important to draw scale map. This enables you to figure out where the fast/slow parts really are. Placing it on paper allows you the freedom to actually design your course rather than depending on luck or chance.





10 Basic Concepts

7.) Use Pointers and Directionals Correctly and Sparingly

Pointers

- A single lay down cone at the base of a standing cone
 - The purpose of a pointer cone is ONLY to indicate the inside of a turn
 - Your car will always turn around a pointer if it is placed correctly








Directional Cones

Directionals



- A series of 3 or more lay down cones to guide the driver to the left or right
- Choose a set number of cones (such as 3 or more) and always use that amount when placing them on the course
 - Creates a recognizable pattern
 - Driver will see it as a directional set and not a downed cone next to a pointer



DO NOT USE

"Hey! Look At Me" (HLAM) cones which are pointers on both sides of a gate





- Pointer cones are supposed to be on the inside of a turn
 - HLAM cones can make a driver turn the wrong way





8.) Line the Course

- Line the course whenever possible
 - It helps Rookies
 - Lessens the chance for a "cross-over"
- The course should NOT be line dependent
 - Successfully driven if the lines are "rained" away
 - This is accomplished by paying close attention to basic concept #5
- The lining of the course is a visual aid in basic course negotiation:
 NOT an indication of the correct line to drive
 - Refrain from forcing competitor to drive over the chalk lines
 - Keep lines close to the cones so they are seen
- What to use (in order of preference)
 - Flour: non-caustic, easy to get, bright on pavement, smells like a Bakery!
 - Marble Dust: non-caustic, hard to find, not bright on pavement



10 Basic Concepts

9.) Place Gates to Avoid Visual Confusion

Gated Courses

Ratio of gate width to gate spacing should be 1 to 3 or greater.

For example, if your gate width is 20 feet the distance between gates would be 60 feet or greater



Å

Miniature Road Courses

Ratio of gate width to gate spacing should be 2 to 1 or less. For example, if your gate width is 20 feet, the distance between gates would be 10 feet or less






Gate Spacing "Rule of Thumb"

- Do not place cones or gates at intervals similar to the width of gates being used
 - For example, do not place gates going around a sweeping turn 25' or 15' apart if all of your gates are 20' wide
 - This creates a visual nightmare called "Cone Hell" since, at speed, all openings appear to be about the same size Arrrrgh!!! Which is gap and which is gate?
- Make all cone walls dense enough so that at any angle, the gaps between them cannot be construed as a gate
- When entering a "box" or walled in turn, place the cones that appear in the approach path closer together and more frequently - creating a dense wall in the driver's line of sight




Plan and Perspective views

- The following examples show a plan view and a perspective view of certain situations so that you can better visualize the cone configuration being indicated
 - What you see below is the basic path that the next 3 examples are going to take



Direction of travel

Plan View










Gates and Pointers

Plan View







10 Basic Concepts – Avoid Visual Confusion

Wall-o-Cones or Miniature Road Course (MRC)

Plan View










The Dreaded "Sea of Pylons"


Plan View









The "Cone Hell" Sweeper



Cones placed at distances roughly equivalent to the gate width will be confusing at speed.












The "Cone Hell" Sweeper



Try to place gates a minimum of 3 times the distance of the gate width used












The "Cone Hell" Sweeper













The "Cone Hell" Lane Change




sea of cones








The "Cone Hell" Lane Change








10 Basic Concepts – Avoid Visual Confusion


Box Turns





10 Basic Concepts – Avoid Visual Confusion

Box Turns



Place the cones that appear in the approach path closer together and more frequently



10 Basic Concepts

10.) Walk & Drive your course with the Intent of Improvement

- Always walk and drive your course after its initial set-up with the intent of changing it to improve the flow
 - I have never drawn a course, set it up and not changed at least one thing
 - Keep the basic concept of your maneuver, but improve it to make it more fun
 - Maybe it was too tight, or too fast, or visually hard to see
 - What ever the shortcoming, this is the perfect time to fix it
- Take a Safety Steward and an experienced Course Designer with you
 - This allows you to address the Safety Steward's safety concerns while maintaining the success of the maneuver
 - You can discuss/analyze any of the suggestions the experienced course designer has to make your design better
- ALWAYS DRIVE the course to find its shortcomings
 - Someone should test drive the course and not Aunt Ethel (unless she is an AutoXer)
 - Make your design changes based on the inputs received and document all changes in your design for future reference

Be a Commercial Artist, NOT a Fine Artist



Agenda

- Fundamentals
- 10 Basic Concepts
- So you have a Blank Piece of Paper...



- Elements, Dimensions and Real Speed
- Summary and Questions



(DOH!! what now???)

- These techniques will enable you to put your ideas and the 10 basic concepts you've just gone over down on a piece of paper
 - I have found that at times, a blank piece of paper can be extremely intimidating
 - The following will hopefully alleviate that problem and make this task easier





Before You Start Your Glorious Creation

- Make the job easier and improve your chances of success acquire or make a reasonable scale map of the event site that contains the following information:
 - The accurate overall shape and size of the course area
 - Map scale information
 - Dimensions of parking stalls, Concrete square dimensions
 - Locations of:
 - Surface anomalies (grates, holes, oil, etc.); Immovable objects (light poles, buildings, curbs, trees, etc.); Boundary features (fences, sidewalks streets, etc.); Entrance and Exits; Elevation changes or sloped sections
- · Address location/logistics of all non-course features on your map as well
 - Site entrance(s)
 - Waiver patrol points
 - Pit areas
 - Grid

- Spectator areas
- Registration
- Technical inspection
- Number of cones

- Timing vehicle/trailer/tent
- Finish placement/run-out




Off Camber Surfaces, Bumpy Lots/Changing Surfaces Why We Care

- Any category beyond Stock can have major issues
 - Even some Stock cars can be broken by these things
- Ground clearance
 - Damage to bodywork/aero, to engine, to frame, etc.
- Suspension travel
 - Bottoming out is not only bad for driving but can break things and in a worst case lead to a rollover
- Getting airborne
 - Powered wheel spins uncontrolled, then can break axles/diffs/trannies when it comes back down
- Hard on driver
 - Think AM, BM, CM, FM, FJr, etc.
- Loss of control potential is larger (spins happen easier)



Off Camber Surfaces, Bumpy Lots/Changing Surfaces What We Care About

- Ridges
- Valleys
- Camber changes
- Grates, holes, patches, metal plates, things to just plain not hit
- Washboard sections
- Concrete seam drop-offs and step-ups
 - A step-up is worse, but a drop-off can be an axle breaker
 - If it's more than an inch, either way, avoid it
- Low areas where water can accumulate






Off Camber Surfaces, Bumpy Lots/Changing Surfaces What To Do

- Cross ridges and valleys at an angle (the shallower the better) while going straight and preferably not braking
 - The closer to parallel with the groove or ridge you are, the shallower the ditch or peak effectively becomes
 - This also lets the corners of the car's suspension work independently to absorb the deflections.
- Put a cone on grate/hole/patch/plate
 - Make it part of the course marking boundary
- Avoid washboard section if possible
 - Traverse at lower speed, or at least with no turning or braking if not
- Avoid low areas if possible, or make the time in them minimal
 - Rain is a factor you can't brake or turn when hydroplaning on a puddle/river/lake
- Reduce speed of crossing for drop-offs and step-ups, cross at angle
 - Try to have cars not braking or accelerating when they cross it





Scale Map of the Topeka North Course Area





Getting Started (Finally...)

Position the finish area first

- Runoff and type of finish
- Define exit/return route to grid
- Location of finish lights
- Clear view from Timing
- Avoid maneuvers at the lights
- Avoid the brakes at the lights

Position the start area next


- Staging line and type of start
- Access from the grid
- Location of the start lights
- Clear view from Timing
- Place sharp turn just prior to or just after the lights to prevent the need of dumping the clutch

Sketch General Route

- Do several general sketches
- Anticipate corner worker positions
- Note boundaries and immovable objects
- Avoid crossovers
- Provide separation between sections



Position the Start and Finish First






Finalizing the Design

- Choose a variety of different types of maneuvers and features
 - Make a list of the desired elements
 - Decide which portions of that route lend themselves to each of the listed elements
- Pick the elements that seem the best for your pathway and fill them in
 - Adjust turn radii and shapes
 - · Add transients where applicable
 - · Ensure a diversity of elements

- Add projected cone locations
 - Don't think chalk line will guide drivers
 - Rain or wind may eradicate those
 - Allow for room driver error
 - Prioritize key cones
 - Repeat cone shapes to create patterns
 - Pointers on apexes
 - Four cone walls on outside of turns
 - Standard gate widths
 - Consistent number of lay downs
 - Avoid Excess cones where not required for a desired visual
 - Allow room for adjustment
 - no course should be expected to be set up exactly as it was drawn
 - 10' minimum movement allowance of individual cones, gates or even entire sections




Finalized Design Example



See next page to view this section



Section from Finalized Design







Course Design and Event Setup Computer Design Analysis

- The following assumes that you have access to a fairly powerful computer with a current Graphics program that utilizes bezier curves and lines such as Adobe Illustrator, Xara, Zoner Draw, Deneba Canvas, Corel Draw, etc.
 - When you input your design into a computer to scale, you can analyze how well the course flows by plotting the probable path of a car
 - Create a probable path of the car using a bezier curve the approximate width of a car
 - Most cars are about 6 feet wide
 - Place your bezier intersections at probable apex points
 - Adjust the bezier curves to create the fastest (shortest) course path
 - Strive to have the line as smooth as possible
 - Make your bezier handles similar in length
 - Do not have bezier handles overlap each other



Computer Design Analysis (continued)










Worker Stations

- Now add the projected course worker stations and projected coverage area
 - Keep coverage distances around 200 feet in any direction or less if possible
 - Position near solid objects if possible/available
 - light pole
 - tree
 - planter, etc.
 - Locate workers on the inside of a turn rather than the outside
 - Anticipate possible directions that a car may spin and avoid those areas
 - Prioritize closeness to the cones likely to be hit
 - slalom cones
 - tight apexes
 - outside walls at ends of significant straights, etc.
 - Try to ensure that workers do not have to cross another area of the course to get to a down cone in their coverage area



Placing Worker Stations





Designing a Safe Finish

- Every change you make will impact somewhere else
- Humans can be totally unpredictable
 - So plan the finish carefully
 - Each site offers its own strengths/weaknesses, and finishes are too often afterthoughts rather than well-planned
 - Ensure adequate room for runout, ingress, egress, timing, and all of the other associated issues
- Some of the things that often don't work to control finish speed:
 - Tight slalom right before the finish lights
 - Finish lights near exit of decreasing-radius turn
- Some of the things that often do work:

• 90 or sharper turn before a straight to lights

Moderate slalom

before a straight to lights

S-turn sequence

before a straight to lights

Notice a pattern?



Consider Human Nature

(stupid humans!)

Allow them to "FLOOR IT" at the finish

- Most drivers tend to floor at the finish in an effort to make up for ALL of the mistakes made up to that point – even if the design does not allow for it
- Since they will do it anyway, (site size allowing) provide opportunity to floor it SAFELY

How can entrants floor it at the finish safely?

- By making them slow enough at the point they begin to floor it for the finish
- In addition, the car MUST be settled when floored or you get a high speed spin
- The turn preceding the straight before the lights must be *completed* (meaning the car is settled and not wagging) ~100' from the lights

Make it safe for everyone by planning for the "unintended line"

- Even when the correct line ends 100' prior to the lights, will the wrong approach end the turn 100' prior to the lights?
 - If not, they will likely be out of control, and flooring it at the finish
- Walk/drive it as intended (on line), and *then* as not intended (not on line)
 - The course will look much different when driven not as intended



Tweaking it at Set Up

Dealing with Acceleration Intoxication

- Impairs the driver's judgment when to safely stop; and nobody brakes at the lights
 - Can result in going through the end of the finish; plan for this
- Define the finish clearly
 - Alternately colored cones after the finish lights; Different flour line pattern;
 Nothing near end of stop box

Allow enough course area for your finish

- Layout the finish first, then route the rest of the course to join the start
- A fast finish should have 200'; or 250'+ after the lights (refer to speed chart)
- Long enough to allow stopping with brakes locked (not the best way to stop)
- Ample buffer after the end of the finish lane (faster = more buffer 75' minimum)

Make it safe for everyone by planning for the "unintended line"

- Test drive it as intended (on-line), and *then* as not intended (not on-line)
 - The course will look much different when driven not as intended



Designing a Safe Finish Checklist


A Safe Finish:

- 1.) Allows enough course area to stop easily
- 2.) Allows the entrant to "floor it" on the last 100' to the finish SAFELY
- 3.) Includes a slowing turn that is completed before the 100' straight to the finish, even if driven incorrectly
- 4.) Has considered and been revised for the "unintended line"
- 5.) Considers what lies beyond the finish lane
- 6.) Does NOT depend on common sense to prevent an incident

Words of Wisdom


- If course length is given up to provide enough run out after the lights, so be it
 - It will only cost about a second to give another 50-70 feet to the finish
- Make sure the "slowing turn" to rein in speeds before the finish, actually slows
- It's better to have folks grumble about lower speeds than it is to have an incident









Starts - Turn Before









Starts - Turn Before






Starts - Turn After








Effectively a Drag Race Start






Large, Expansive Sites





Large, Expansive Sites (continued)





Small Or Odd Shaped Lot Utilization

1200'


SCCA Nationals East Course Size Comparison



700'




Small Or Odd Shaped Lot Utilization Estadio Monumental vs. SCCA Nationals East Course Area






Small Or Odd Shaped Lot Utilization Estadio Monumental






Small Or Odd Shaped Lot Utilization Estadio Monumental






Small Or Odd Shaped Lot Utilization Lumber Yard vs. Autocross Nationals East Course Area






Small Or Odd Shaped Lot Utilization Lumber Yard Site





Small Or Odd Shaped Lot Utilization Lumber Yard Site






So You Have a Blank Piece of Paper Small Or Odd Shaped Lot Utilization My Frozen Butte vs.











So You Have a Blank Piece of Paper Small Or Odd Shaped Lot Utilization COTA vs. Autocross Nationals East Course Area






Small Or Odd Shaped Lot Utilization Circuit of the Americas (COTA)






Narrow Road Course Sites






Narrow Road Course Sites (continued)




Note that course direction is same both days



Long Skinny Sites





- How about a "long and skinny" event site?
 - Avoid slalom down, 180° turn, slalom back
 - **Balance** between slaloms, sweeping turns, and offset gates, just as you would in an open lot





Other Difficult Shaped Sites








Useful Tricks for Limited Space

- Shared walls
 - Placement may limit to one car at a time
- Out-and-back through section
- Variety through gate spacing







Agenda

- Fundamentals
- 10 Basic Concepts
- So you have a Blank Piece of Paper...
- Elements, Dimensions and Real Speed




Summary and Questions



Disclaimers

- Approximations are inherent in the methods used
 - Sweepers are not usually constant radius arcs
 - Straightways often are not perfectly straight
- What makes a quick autocross car is not just pulling high lateral G's and acceleration





Course Design and Event Setup Cornering Speeds in MPH

- The following table is based on sustained lateral G's, not peak lateral G's
- Calculations based on a constant radius, instantaneous transition model
 - 0.90 Lateral G's from stock cars on OEM tires
 - 1.10 lateral G's from prepared Street Class cars on tires with a 200 treadwear rating
 - 1.20 lateral G's from a non-winged car such as C Mod,
 - 1.45 lateral G's from a winged mod car


Lateral Ca							Ra	idius (of Turr	n in Fe	et						
Lateral Gs	20	30	40	50	60	70	80	90	100	125	150	175	200	250	300	350	400
0.90	16	20	23	26	28	31	33	35	37	41	45	49	52	58	64	69	73
0.95	17	21	24	27	29	32	34	36	38	42	46	50	53	60	65	71	75
1.00	17	21	24	27	30	32	35	37	39	43	47	51	55	61	67	72	77
1.05	18	22	25	28	31	33	35	38	40	44	49	52	56	63	69	74	79
1.10	18	22	26	29	31	34	36	38	41	45	50	54	57	64	70	76	81
1.15	19	23	26	29	32	35	37	39	41	46	51	55	59	66	72	78	83
1.20	19	23	27	30	33	35	38	40	42	47	52	56	60	67	73	79	85
1.25	19	24	27	31	34	36	39	41	43	48	53	57	61	68	75	81	87
1.30	20	24	28	31	34	37	39	42	44	49	54	58	62	70	76	83	88
1.35	20	25	28	32	35	38	40	43	45	50	55	59	64	71	78	84	90
1.40	20	25	29	32	35	38	41	43	46	51	56	61	65	72	79	86	92
1.45	21	26	29	33	36	39	42	44	47	52	57	62	66	74	81	87	93



Slalom Speeds in MPH

Lateral G's						Slal	om Spa	cing in	Feet					
Lateral G S	45	50	55	60	65	70	75	80	85	90	95	100	110	120
0.90	30	33	36	39	42	46	49	52	55	59	62	65	72	78
0.95	30	34	37	40	44	47	50	54	57	60	64	67	74	80
1.00	31	35	38	41	45	48	52	55	58	62	65	69	75	82
1.05	32	35	39		46	49	53	56	60	63	67	70	77	84
1.10	33	36	40	43	47	51	54	58	61	65	68	72	79	86
1.15	34	37	41	44	48	52	55	59	63	66	70	74	81	88
1.20	34	38	42	45	49	53	57	60	64	68	71	75	83	90
1.25	35	39	42	46	50	54	58	61	65	69	73	77	84	92
1.30	36	39	43	47	51	55	59	63	67	70	74	78	86	94
1.35	36	40	44	48	52	56	60	64	68	72	76	80	88	96
1.40	37	41	45	49	53	57	61	65	69	73	77	81	89	97
1.45	38	42	46	50	54	58	62	66	70	74	79	83	91	99
1.50	38	42	47	51	55	59	63	67	72	76	80	84	92	101

- Expect <0.90 from stock cars on street tires, 1.10 g's from more prepared cars on race tires, 1.20 g's from a non-winged car such as C Mod, and 1.45 g's from a winged mod car
 - Calculations are based on a constant radius, instantaneous transition model





Acceleration and Braking Distances in Feet

Acceleration distances


- The blue/gray portion is used to estimate distance needed to reach a certain speed
- Based on a quick ST Car, which could do 0 60 mph in 4.1 secs

Braking distances

- The pink half of the chart estimates braking distances of lower performance cars and stop box length
- Based on constant 0.8 g braking,(typical published vehicle maximum baking effort on street tires)

	Starting Speed	Target Speed	Needed Distance
Acceleration Section	35	65	191
Braking Section	65	40	110

Starting	Target Speed in MPH													
Speed in MPH	0	20	25	30	35	40	45	50	55	60	65	70	75	80
0	0	15	25	37	53	70	94	121	149	180	222	267	311	358
20	17	0	12	26	42	62	88	118	149	182	228	277	338	403
25	26	9	0	14	31	50	77	107	138	171	218	268	330	397
30	38	21	11	0	17	36	63	94	125	158	206	257	320	387
35	51	34	25	14	0	19	47	78	109	143	191	243	307	375
40	67	50	41	29	16	0	28	59	91	125	173	226	291	361
45	85	68	58	47	33	18	0	31	62	96	145	198	264	335
50	104	88	78	67	53	38	20	0	31	65	114	167	234	305
55	126	110	100	89	75	60	42	22	0	34	84	138	205	277
60	150	134	124	113	99	83	66	46	24	0	50	105	173	246
65	176	160	150	139	125	110	92	72	50	26	0	54	123	197
70	205	188	179	167	153	138	120	100	78	54	28	0	69	143
75	235	218	209	197	184	168	150	130	109	85	58	30	0	74
80	267	251	241	230	216	200	183	163	141	117	91	63	32	0





Practical Application

...to match speed of the following turn


Start with the speed of the preceding turn... ...to calculate the speed of following Straight

To calculate the distance needed to slow down...



Element Dimensions and Real Speed

Course Design and Event Setup Practical Application



Start Speed	(A)	Distance (B)	Ending Speed
35		143		60
Brake Speed	End	speed (C)	Br	ake Distance (D)
60		29		113

Calculate braking distance

- Determine speed of turn A
- Determine speed of straight B
 - Speed of A and length of straight = speed


Starting						Targe	t Spe	ed in	MPH					
Speed in MPH	0	20	25	30	35	40	45	50	55	60	65	70	75	80
0	0	15	25	37	53	70	94	121	149	180	222	267	311	358
20	17	0	12	26	42	62	88	118	149	182	228	277	338	403
25	26	9	0	14	31	50	77	107	138	171	218	268	330	397
30	38	21	11	0	17	36	63	94	125	158	206	257	320	387
35	51	34	25	14	0	19	47	78	109	143	191	243	307	375
40	67	50	41	29	16	0	28	59	91	125	173	226	291	361
45	85	68	58	47	33	18	0	31	62	96	145	198	264	335
50	104	88	78	67	53	38	20	0	31	65	114	167	234	305
55	126	110	100	89	75	60	42	22	0	34	84	138	205	277
60	150	134	124	113	99	83	66	46	24	0	50	105	173	246
65	176	160	150	139	125	110	92	72	50	26	0	54	123	197
70	205	188	179	167	153	138	120	100	78	54	28	0	69	143
75	235	218	209	197	184	168	150	130	109	85	58	30	0	74

Lateral				_					f Tu								
Gs	20	0 30 40 50 60 70 80 90 100 125 150 175 200 250 300 350 400															
1.10	18	22	26	29	31	34	36	38	41	45	50	54	57	64	70	76	81

- Determine speed of turn C
- Calculate braking distance needed for D
 - Speed of B and target speed of C = braking distance
- 143' acceleration + 113' brake = 256' straight



Practical Application



Start Speed	(A)	Distance (B)	Ending Speed
35		143		60
Brake Speed	End	speed (C)	Br	ake Distance (D)
60		0		150

- Calculate stop box length
 - Determine speed of turn A
 - Determine speed of straight B
 - Calculate braking distance to 0 mph needed for C


Starting	Target Speed in MPH													
Speed in MPH	0	20	25	30	35	40	45	50	55	60	65	70	75	80
0	0	15	25	37	53	70	94	121	149	180	222	267	311	358
20	17	0	12	26	42	62	88	118	149	182	228	277	338	403
25	26	9	0	14	31	50	77	107	138	171	218	268	330	397
30	38	21	11	0	17	36	63	94	125	158	206	257	320	387
35	51	34	25	14	0	19	47	78	109	143	191	243	307	375
40	67	50	41	29	16	0	28	59	91	125	173	226	291	361
45	85	68	58	47	33	18	0	31	62	96	145	198	264	335
50	104	88	78	67	53	38	20	0	31	65	114	167	234	305
55	126	110	100	89	75	60	42	22	0	34	84	138	205	277
60	150	134	124	113	99	83	66	46	24	0	50	105	173	246
65	176	160	150	139	125	110	92	72	50	26	0	54	123	197
70	205	188	179	167	153	138	120	100	78	54	28	0	69	143


ĺ	Lateral							Radi	Radius of Turn in Feet														
	Gs	20	0 30 40 50 60 70 80 90 100 125 150 175 200 250 300 350 400														400						
	1.10	18	22	26	29	31	34	36	38	41	45	50	54	57	64	70	76	81					


- Be sure to add plenty of margin to the actual stop box so that all cars can easily slow/stop within the box
 - 150' brake + 50' reaction time = 200' stop box
 - In addition, when raining, these stop distances increase considerably (about double)




Flow Analysis









(does not slow car)

 55 mph turn + 100' straight = ~68mph at the lights on DOT Race Tires

 Stopping distance ~200' in a 200' stop box – and no one stops right at the lights…

Starting	Target Speed in MPH													
Speed in MPH	0	20	25	30	35	40	45	50	55	60	65	70	75	80
0	0	15	25	37	53	70	94	121	149	180	222	267	311	358
20	17	0	12	26	42	62	88	118	149	182	228	277	338	403
25	26	9	0	14	31	50	77	107	138	171	218	268	330	397
30	38	21	11	0	17	36	63	94	125	158	206	257	320	387
35	51	34	25	14	0	19	47	78	109	143	191	243	307	375
40	67	50	41	29	16	0	28	59	91	125	173	226	291	361
45	85	68	58	47	33	18	0	31	62	96	145	198	264	335
50	104	88	78	67	53	38	20	0	31	65	114	167	234	305
55	126	110	100	89	75	60	42	22	0	34	84	138	205	277
60	150	134	124	113	99	83	66	46	24	0	50	105	173	246
65	176	160	150	139	125	110	92	72	50	26	0	54	123	197
70	205	188	179	167	153	138	120	100	78	54	28	0	69	143
75	235	218	209	197	184	168	150	130	109	85	58	30	0	74
80	267	251	241	230	216	200	183	163	141	117	91	63	32	0

Light


pole



Element Dimensions and Real Speed

- This section of the book will address is how you, as a course designer, can relate course content and size to how fast the competitors cars might actually go
 - This section is important to understand since it has a real life example as to why you
 must make your courses "equalizer courses" as outlined in the 6th basic concept
 (Horsepower vs. Handling)
- This section will address:
 - Sweeper speeds
 - Radius of a turn
 - Cornering G's of a car

- Straightway speeds
 - Length of straight
 - · Acceleration times








More Disclaimers

- All calculations shown in this section are based on Car magazine road test data
- The variables include:
 - Type of surface used for testing
 - Type and size of the tires on the car
 - Preparation level of the car
 - shocks
 - alignments
 - bushings, etc.
 - Abilities of the test driver
- Approximations are inherent in the methods used
 - Sweepers are not usually constant radius arcs
 - Straightways often are not perfectly straight
- What makes a quick autocross car is not just pulling high G's and acceleration



Sweeper Speeds


• The relationship of the radius of the turn and the cornering G's is shown in the table below:



		Miles per hour					
_		Radius 50'	Radius 75'	Radius 100'			
	0.90	25.9	31.7	36.6			
6	0.85	25.1	30.8	35.6			
Force	0.84 ('93 Camaro)	25.0	30.6	35.3			
9	0.82 ('93 Sentra)	24.7	30.2	34.9			
	0.80	24.4	29.9	34.5			



Straightway Speeds




- Acceleration times
 - Magazine test data usually include times for:
 - 0 30 mph
 - 0 40 mph
 - 0 50 mph
 - 0 60 mph
 - 0 70 mph
 - Calculation of distance covered is based on the area beneath the curve on a plot of velocity versus time



Camaro Specifications

TECH DATA



'93 Chevrolet Camaro Z28

Talon To


	CHASSIS
Suspension	
	Upper and lower control arms.
	coil springs, anti-roll bar
Rear	Solid axle, multilink with trailing arms
	and track bar, coil springs, anti-roll bar
Steering	-
Туре	Rack and pinion
Ratio	14.4:1
	2.3
	39.0
Brakes	•
nt, type/dia., in	Vented discs/10.9
type/dia., in	Vented discs/11.4
nd tires	
in	

`~ria!

PERFORMANCE AND TEST DATA Acceleration, sec 0-30 mph 0-70 mph8.2 0-80 mph Standing quarter mile sec @ mph......14.7 @ 96.9 Braking, ft 30-0 moh31 Speed through 600-ft stalom, mph63.6 Speedometer error, mph Indicated Interior noise, dBA Idling in neutral Steady 60 mph in top gear......75



CamaroVelocity vs. Time











Sentra Specifications



Houston Region SCCA Sports Car Club of America

Element Dimensions and Real Speed


Sentra Velocity vs. Time



Under full acceleration from 30 to 70mph, the Sentra will travel 627.75 feet in 8.1 seconds



Camaro and Sentra Velocity vs. Time



The Sentra would have to travel 2.6 seconds longer and 201.5 feet farther than the Camaro to reach 70 mph



How a Straight Gives Time to Power

- How much effect can a big straight have on the competition?
 - · Camaro:
 - 30 70 in 5.5 seconds; 426 feet
 - Sentra:
 - 30 70 in 8.1seconds; 628 feet
 - Also reaches 351 feet in 5.5 seconds (Camaro = 426 feet in 5.5 seconds)
 - Finally reaches 426 feet in 6.35 seconds (which the Camaro did .85 seconds quicker)
- O.K. so what does that mean?
 - The time advantage for the Camaro over a 426 foot straight section is about 0.85 seconds, or a total distance of 75 feet
- How could the Sentra make up that difference?
 - Either a secret nitrous container or go faster in the turns
 - To go faster in the turn, it needs a higher entry speed into the straight by 9.2 mph, so it would need to pull about 71% more G's in the sweeper
 - Hey folks That's 1.43 G's and that ain't gonna happen!



Why Do We Care?

- How a straight gives time to a car with power
 - The Camaro isn't classed with the Sentra, but classes do contain such mixtures
 - For example in 2021, the FStreet class contains:
 - 2008 Mercedes C300
 - 3,700 pounds / 228 horsepower = 16.22 lbs/hp (where bigger = slower)
 - 2015 Camaro SS 1LE
 - 3,884 pounds / 426 horsepower (oh my...) = 9.12 lbs/hp
 - That is a 78% difference in power to weight ratio between cars in the same class
- So what does that have to do with a Camaro/Sentra comparison?
 - Sentra
 - 2,600 pounds / 140 horsepower = 18.60 lbs/hp
 - 1993 Camaro V8
 - 3373 pounds / 275 horsepower = 12.30 lbs/hp
 - That is only a **51% difference** between the cars in our example

Horsepower to weight disparities within class structure make it essential to balance your course design between power and handling



Overall Speed in Autocross Course Design

• How fast do we go?

• Why do we care?

The following is critical to allow us to continue our sport...



What the Rules Say

- "...should not normally exceed the mid-60s (mph) for the fastest Street and Street Touring® category cars"
 - This doesn't mean the average: it means the maximum
 - Don't try to get cute with "normally"



Why Is Speed Compliance So Important?

- Keywords (from Risk Management):
 - Negligence
 - Gross Negligence
 - Release/Waiver Effectiveness
 - Punitive Damages
 - Compensatory Damages
 - Insurance Rates
 - Coverage Refusal



What's The Point?

- A good Street or Street Touring® car can get a lot more speed a lot more quickly than many people realize (remember, the rule says "fastest")
- It's easy to figure these things out in terms of something simple like the length of a straightaway, or the size (radius) of a turn
- This is different from the "I could have sworn they'd have to lift there" problem



What Does All This Mean?

- A Stock Z06 can get from 30 mph (speed in a sweeper of ~65' Radius) to 80 mph in just over 400 feet
- There are probably ST Cars that can do it even quicker
- Pure straights much over 400 feet in length are iffy; much longer ones are just plain irresponsible



What Can You Do?

- Have higher density of quick elements that are not straights; which can be plenty of fun
 - Connected sweepers ("esses")
 - Lane changes
 - Big slaloms (70'-80' spacing)
 - Elements that require throttle modulation and/or even (horrors) a little braking



What Should You NOT Do?

- As administrators:
 - Don't let course designers think they have the last word (Event Chairs and Safety Stewards do)
 - Don't rationalize "letting it go this time"
 - Don't listen to competitors who whine about not being able to go "real fast"



What Should You NOT Do?

- As designers:
 - Don't focus on "pushing the envelope" with regard to speed
 - Focus instead on delivering a challenging, fun driving experience that provides quality competition
 - Don't put a tightening transient element near the end of a fast stretch, to slow cars down (recipe for sedan rollovers)



Protect Our Sport

- If Autocross, as the Rules define it, isn't what someone wants to be driving, they should go try something else
- These folks should not be allowed to corrupt our sport into something it was never meant to be: they put us all at risk!



Agenda

- Fundamentals
- 10 Basic Concepts
- So you have a Blank Piece of Paper...
- Elements, Dimensions and Real Speed
- Summary and Questions





Contact Information

- Remember, the more courses you design and set up, the better your courses will be
- Please feel free to contact me with any future questions
 - I can be reached as listed below:
 - Home of the Criminally Insane
 Attention: Roger H. Johnson
 3910 Gallaher Court
 Missouri City, Texas 77459
 - (281) 217-5310

home/cell

Central Time

- rogerthereal@entouch.net
- Complete Course Design Booklet
 - https://www.houscca.com/autocross/course-design-resources/
 - Then scroll to the bottom of the page and select Solo Course Design Manual